

Adams-Harris Pattern Company

Rosy Winter SD

Designed and fitted for ResinSoul Dia

Yardage and Notions

Yardage: 1/3-yard jersey knit

Notions: 1/2-yard ribbon
2 mini snap sets

General Cutting and Marking Directions

1. Lay out all pieces following the grainlines on the pattern. Cut the number of pieces indicated on the patterns. Check pattern before cutting to see if you will need to paste large pieces together first.
2. Cut notches no deeper than 1/8 inch. All seam allowances are 1/4 inch in less otherwise indicated in the sewing directions.
3. All garment pieces are sewn with the right sides together in less otherwise noted.
4. When interfacing, use fusible and press to fabric before cutting out pattern.
5. With smaller patterns I do not recommend serging seams as this creates bulk. I use a fray-checking product as needed. If you are serging use a smaller width on your machine, I use 2mm. You will have to determine if you want to serge/zigzag or not.
6. As with all sewing projects, you will get better results if you press as you go, fit as you go and tie-off your thread ends rather than back stitching.
7. When talking about left and right, it always means the left or right as the garment is worn.

Sewing Directions:

Paste the back dress sleeve bottom to the dress pattern before cutting.

1. Sew a large running stitch between notches on front bodice, and then gather to fit front skirt between notches.
2. Join front bodice to front skirt with the right sides together.
3. Join the front bodice to the back sleeves along the should line with right sides together.
4. Press seams open.
5. Turn up the sleeve hems, matching wrong sides together and press in place.
6. Topstitch sleeve hems.
7. Hand baste the neckline hem, 1/4-inch with wrong sides together. Then topstitch the neckline hem in place. Press out neckline.
8. Tack the ribbon trim to the front of the dress on the empire seam so that the tails of the ribbon are toward the center front.
9. Join the front and back side seams with right sides together.
10. Join the center back of the dress starting at the dot mark and finishing at the hem.
11. Turn up the bottom hem with wrong sides together and press in place. Then topstitch the hem.
12. Press the left back seam allowance toward the left forming a placket, and sew the snap sets to the placket opening.
13. Tie the ribbon in a bow at the center front or back of the dress.